

UK

# **TRUST WIRELESS DESIGN & WORK TABLET 100**

**User manual**

Version 2.0

## Thank you

Thank you very much for purchasing this product from the Trust range. We wish you hours of fun with it. Please read this manual carefully before using the product.

## Registration

Register your purchase now at the Trust Internet site, [www.trust.com](http://www.trust.com), so that you are able to receive optimal guarantee and service support. You will be automatically informed of developments to your product and of other Trust products. You will also have the chance to win some spectacular prizes.

## Copyright statement

No part of this instruction manual may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's own personal use, without prior written permission from the manufacturer.

## Disclaimer statement

The manufacturer specifically disclaims all warranties, either express or implied, including, but not limited to, implied warranties for the marketability and suitability for a particular purpose, with respect to the software, the accompanying product manual(s) and written material, and all other accompanying hardware. The manufacturer reserves the right to revise or make improvements to its product at any time and without obligation to notify any person of such revisions or improvements.

In no event shall the manufacturer be liable for any consequential or incidental damages, including any loss of business profits or any other commercial damages, arising out of the use of its products.

All company or product names are trademarks or registered trademarks of their respective owners.

## Contents

1. Introduction .....	2
1.1 Conventions in the manual .....	2
1.2 Contents of the package.....	2
1.3 Minimum system requirements .....	2
2. Safety.....	3
2.1 General .....	3
2.2 Batteries .....	3
3. 'Trust Design & Work Tablet 100' functions.....	3
4. Installation .....	4
4.1 Inserting batteries .....	4
4.2 'Trust Design & Work Tablet 100' driver program installation .....	4
4.3 Art Dabbler 2.1 installation.....	5
4.4 PenSoft installation.....	8
4.5 CADIX 98 installation .....	11
5. Use of the Tablet .....	15
5.1 Adjusting sensitivity .....	15
5.2 Adjusting the work surface .....	17
6. Using the software .....	17
6.1 Art Dabbler 2.1 .....	17
6.2 PenSoft.....	20
6.3 CADIX98 .....	21
7. Troubleshooting.....	21
8. Specifications .....	22
9. Trust Customer Care Centres .....	23

## 1. Introduction

This instruction manual is intended for users of the Trust Wireless Design & Work Tablet 100 (Design & Work Tablet 100). Some computer experience is necessary when installing this product. When in doubt, consult one of the Trust Customer Care Centres. The last page of the electronic manual, as well as the back of the printed quick installation manual, contain more information about these Customer Care Centres.

### 1.1 Conventions in the manual

The following conventions have been used in this manual to indicate instructions:

- <**key**> Here you should press a key. The name of the key is given between brackets.
- 'System'** This is a specific term used in a program. These are the terms used by, for example, Microsoft Windows 98.
- [**DIR**] Key in the text shown in square brackets [....].
- {**Term**} The text between the accolades {....} is the English term, e.g. {File} which appears in the associated figure.

Additional information is shown as follows:

**NOTE:** *If you connect the 'Trust Design & Work Tablet 100' to a USB HUB, the USB HUB must have its own power source.*

The examples assume that the letter "D" has been assigned to your CD-ROM drive. If your system uses a different drive letter for your CD-ROM drive, such as "E", you should replace the drive letter "D" in the text with "E".

### 1.2 Contents of the package

Before reading the user manual, check the contents of the package. It must contain:

- Trust Design & Work Tablet 100
- Wireless 3-button pen
- CD-ROM with driver program, applications and manuals
- CD-ROM with ART DABBLER 2.1
- Quick installation manual
- Type AAAA battery

Should anything be missing or be damaged, please contact one of the Trust Customer Care Centres. You will find more information about these at the back of this manual.

### 1.3 Minimum system requirements

- Pentium 133 MHz CPU
- USB port
- Windows 98
- 32 MB RAM
- 50 MB hard disk space available
- 4X CD-ROM player

## 2. Safety

### 2.1 General

1. Do not use this device in a damp environment.
2. Do not try to repair this device yourself.
3. Under the following circumstances, have the device repaired by qualified personnel:
  - a) The cable or plug is damaged or worn;
  - b) Fluid has entered the device;
  - c) The device has been dropped and/or the housing is damaged;
4. Position the device so that the cables cannot be damaged.

### 2.2 Batteries

1. The batteries are not rechargeable. Do not try to recharge them, because this may cause an explosion.
2. Never throw the batteries on an open fire. The batteries may explode.
3. Never drill into the batteries.
4. Keep the batteries out of the reach of small children.

When the batteries are empty, ask your local authority where you can dispose of them.

## 3. 'Trust Design & Work Tablet 100' functions




Figure 1: 'Trust Design & Work Tablet 100' functions

	Description	Function
A	LED	Goes on when the 'Trust Design & Work Tablet 100' has been properly installed.
B	Function Keys F1 through F8	These have the same function as function keys F1 through F8 on the keyboard. The driver program does have to be installed.
C	Pen Holder	Place to put the pen while not in use.
D	Work area	You can make the drawing here.
E	Pen point	Equivalent to left mouse button.
F	Pen button	Equivalent to middle mouse button.
G	Pen button	Equivalent to right mouse button.

Table 1: Trust Design & Work Tablet 100 functions

## 4. Installation

### 4.1 Inserting batteries

Insert the batteries in the 'Trust Design & Work Tablet 100' pen as follows.



Figure 2: inserting batteries

1. Twist the top of the pen to the left until it comes apart.
2. Insert the battery in the compartment as shown in figure 2. You can also read on the inside of the battery compartment how the batteries must be inserted.
3. Next, twist the top of the pen on again.

**Note:** *Inserting the batteries incorrectly may cause damage.*

**Note:** *Only replace the battery with an equivalent type (alkaline type batteries or rechargeable NiMH).*

### 4.2 'Trust Design & Work Tablet 100' driver program installation


1. Insert the CD-ROM in your CD-ROM player and the installation program will start up automatically. If this does not happen, start up 'Setup.exe' on the CD. Figure 3 will appear.




UK

**Figure 3:** Driver program installation

- Click on 'Trust Design & Work Tablet 100' to install the driver program. Figure 4 will appear.

**Figure 4:** driver program installation

- Click on 'Next' to start the installation. After installation, Figure 5 will appear.

**Figure 4:** driver program installation

- Connect the 'Trust Wireless Design & Work Tablet 100' to a free USB port.

The driver program installation is completed. Go on to chapter 4.3 for installation of Art Dabbler 2.1.


#### **4.3 Art Dabbler 2.1 installation**

Art Dabbler 2.1 is a drawing program which you can use with your 'Trust Design & Work Tablet 100'. Follow the instructions below for installation of Art Dabbler 2.1.

The Art Dabbler 2.1 program is included on a separate CD-ROM. To install it, follow the directions below.


## Trust Wireless Design & Work Tablet 100

1. Insert the Art Dabbler CD-ROM in your CD-ROM player.
2. If the CD does not start up automatically, proceed as follows.
3. Click on 'Run' in the Start menu.
4. Type in [D:\English\Setup.exe] for the English installation, [D:\German\Setup.exe] for the German installation or [D:\French\Setup.exe] for the French installation and click on 'OK'. Figure 5 will appear.



**Figure 5: Art Dabbler 2.1 installation**

5. Click on 'Next'. Figure 6 will appear.



**Figure 6: Art Dabbler 2.1 installation**

6. Select 'Typical' and click on 'Next'. Figure 7 will appear.




Figure 7: Art Dabbler 2.1 installation

7. Click on 'Next'. Figure 8 will appear





Figure 8: Art Dabbler 2.1 installation

## Trust Wireless Design & Work Tablet 100

- Click on 'Next'. Art Dabbler 2.1 is now being installed. After installation, Figure 9 will appear.



**Figure 9: Art Dabbler 2.1 installation**

- Click on 'Finish' to complete installation of Art Dabbler 2.1

Installation of Art Dabbler is complete. For installation of other programs you must remove the Art Dabbler 2.1 CD-ROM and insert the Trust CD-ROM in your CD-ROM player. Repeat step 1 from chapter 4.2. Figure 3 will appear.

See chapter 4.4 for installation of PenSoft.

### 4.4 PenSoft installation

PenSoft is a program which recognises handwriting. Follow the instructions below for installation of PenSoft.

- Go to the installation screen and click on 'Install PenSoft', see Figure 3. Figure 10 will appear.



**Figure 10: PenSoft installation**

- Select the language in which PenSoft will be installed.

- Click on 'GO' to continue the installation. Figure 11 will appear.



**Figure 11: PenSoft installation**

- Click on 'Next'. Figure 12 will appear.



**Figure 12: PenSoft installation**


## Trust Wireless Design & Work Tablet 100

5. Click on 'Accept' to accept the licence and continue the installation. Figure 13 will appear.




**Figure 13: PenSoft installation**

6. Click on 'Next'. Figure 14 will appear.



**Figure 14: PenSoft installation**

7. Click on 'Next'. Figure 15 will appear.



**Figure 15: PenSoft installation**

8. Click on 'Install'. PenSoft is now being installed. After installation, Figure 16 will appear.



**Figure 16: PenSoft installation**

9. Click on 'Finish' to complete installation of PenSoft and restart the computer.

Installation of PenSoft is completed. See chapter 4.5 for installation of CADIX 98.

#### 4.5 CADIX 98 installation

CADIX 98 is a screen protection program which recognises handwriting. For installation of CADIX 98, follow the directions below.


## Trust Wireless Design & Work Tablet 100

1. Go to the installation screen and click on 'Install CADIX 98'. See Figure 3. Figure 17 will appear.



**Figure 17: CADIX 98 installation**

2. Click on 'Next'. Figure 18 will appear.



**Figure 18: CADIX 98 installation**

3. Select 'Graphics Tablet' and click on 'Next'. Figure 19 will appear.




Figure 19: CADIX 98 installation

4. Click on 'Next'. Figure 20 will appear.




Figure 20: CADIX 98 installation

5. Click on 'Yes'. CADIX 98 is now being installed. After installation, Figure 21 will appear.



**Figure 21: CADIX 98 installation**

6. Click on 'OK'. Figure 22 will appear



**Figure 22: CADIX 98 installation**

7. Click on "Yes" to complete installation of CADIX 98 and restart the computer.


You have completed installation of CADIX 98. See chapter 6 for using the software.

## 5. Use of the Tablet

### 5.1 Adjusting sensitivity


**Note:** *The function of the pen may be affected by the mouse being connected, therefore take the pen off the tablet when the mouse which is connected is in use.*

The sensitivity of the pen supplied with the tablet is adjusted in the following manner:




**Figure 23: Pen settings**

1. Click on the tablet A icon at the bottom right on the tool bar. See Figure 23. Figure 24 will appear.




**Figure 24: Pen settings**

2. Click on the 'Buttons' menu. Figure 25 will appear.



**Figure 25: Pen settings**

3. Different functions can be assigned to the buttons (B & C) on the pen. To do this, click on the arrow to the right intended for this.
4. If you want to cancel the settings, press ‘Default’ (D) to activate the factory settings.
5. The pen pressure can be adjusted by moving the slide (E) up or down.
6. Click on ‘Test’ to test the pen pressure. Figure 26 will appear. You can test the pen pressure here.




**Figure 26: Testing pen pressure**

7. Press on the cross on the top right ‘X’ to turn the screen off.
8. Press on ‘OK’ (Figure 7) to save the settings.

## 5.2 Adjusting the work surface

For adjusting the work surface you may select centimetres (cm) or inches (inch). Click on the specified format in Figure 24 to do this.

1. Click on the 'Control' menu (see Figure 23). Figure 27 will appear.



**Figure 27: Setting the work surface**

2. Change the specified work surface and press 'OK' to save the settings.

## 6. Using the software


### 6.1 Art Dabbler 2.1

Art Dabbler 2.1 is a drawing program with a large number of options.

Follow the instructions below for adjustment and use of Art Dabbler 2.1.

**Note:** The enclosed CD-ROM contains the manual.

1. Open the Art Dabbler program. Figure 28 will appear.



**Figure 28: working with Art Dabbler 2.1**

2. Go to Edit and select Add Page (see Figure 29). Now you have created a new page you can work on.

## Trust Wireless Design & Work Tablet 100




Figure 29: working with Art Dabbler 2.1

3. Go to the tool drawer by pulling the handle. Figure 30 will appear.



Figure 30: working with Art Dabbler


4. Click on the tools and the size of the tools (the red triangle) you want to use. After selecting, close the drawer.
5. From the current colour palette at the front of colour drawer C (see Figure 28), select a colour you want to use or open the colour drawer and select a new palette. See Figure 31. Close the drawer when you have finished.



UK

**Figure 31: working with Art Dabbler 2.1**

6. Now, you can go to the structure drawer C (see Figure 28) to select the paper you want to draw on. Figure 32 will appear.



**Figure 32: working with Art Dabbler 2.1**

You now have the correct tools, structure and colours and you can start drawing. To get help with the different drawing techniques, select 'Tutors'.

7. Click on 'Tutors' and select the topic about which you want more information.



**Figure 33: working with Art Dabbler 2.1**

Now make your own art work or follow the instructions of the tutor.

8. When you are done, you probably want to save your work. Go to 'File' and click on 'Save page as' (see Figure 28). Art Dabbler can save pages as different types of files. Type in the file name and indicate the type of file, for example TIFF.
  9. When you are done with the current page and you want to continue with a different one, return to item 2.
- This was a short description of Art Dabbler. For more information, see the enclosed manual of this Program.

## 6.2 PenSoft

For using the PenSoft program we refer you to the help function in the program or the manual on CD.

### 6.3 CADIX98

For using the CADIX98 program we refer you to the help function in the program or the manual on CD.

## 7. Troubleshooting

Problem	Cause	Possible solution
Windows does not find new equipment after the tablet is connected.	The computer's USB port does not function.	Delete the USB port from equipment management and re-install it.
Computer jams when operating via USB.	USB port shares an IRQ with another device.	Remove cards from the computer or arrange the IRQs differently
'Trust Design & Work Tablet 100' is marked with an exclamation mark '!' in 'Equipment management'.	Tablet connected to a USB HUB without power.	Connect the camera to a USB HUB with power or to a USB port of the computer.
Pen does not respond.	Battery is empty.	Replace the battery. See chapter 5.1.
	Battery inserted incorrectly.	Reinsert the battery. See chapter 4.1.
Pen responds too slowly / quickly.	Sensitivity of the pen adjusted incorrectly.	Adjust the pen. See chapter 5.1.
Standard mouse does not function any longer.	Mouse and pen interfere with each other.	Remove the pen from the tablet when the mouse is in use.
Small work surface.	Work surface set too small.	Adjust the work surface. See chapter 5.2
Sudden failure.	Low battery voltage.	Replace the battery. See chapter 4.1.
No connection to the computer.	Bad cable connection.	Re-connect the cable. See item 4 of chapter 4.2.

**Table 2: troubleshooting**

Register your product via ([www.trust.com](http://www.trust.com)), entitling you to optimum warranty and service support such as up-to-date FAQ and the latest drivers. In addition, you will automatically be informed of the development of your and other Trust products. And you have a chance to win spectacular prizes.

If you still have problems after trying these solutions, please contact one of the Trust Customer Care Centres. You can find more information at the back of this instruction manual. Please have the following information available:

- The article number of the device. This is: 12050;
- Hardware data;
- Operating system + version;
- A good description of what exactly does not function;
- A good description of when exactly the problem occurs.

## 8. Specifications

Work area	4" x 3"
Resolution	3048 lpi
Connection	USB
Pen battery	Type AAAA

**Table 3: specifications**

**UK**

## 9. Trust Customer Care Centres

<b>Inhabitants of Great Britain and Ireland should contact:</b>	
	<b>GB Office</b>
From: 9:30 – 17:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support.uk@trust.com">support.uk@trust.com</a> Fax +44-(0)1376-514633 Tel. +44-(0)1376-500000
<b>Inhabitants of Italy should contact:</b>	
	<b>Italian Office</b>
From: 9:00 – 13:00 / 14:00 - 18:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support.it@trust.com">support.it@trust.com</a> Fax 051-6635843 Tel. 051-6635947
<b>Inhabitants of France and North Africa should contact:</b>	
	<b>French Office</b>
From: 9:00 – 17:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support.fr@trust.com">support.fr@trust.com</a> Fax +33-(0)1-48174918 Tel. +33-(0)803-083080
<b>Inhabitants of Germany should contact:</b>	
	<b>German Office</b>
From: 9:00 – 17:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support.de@trust.com">support.de@trust.com</a> Fax 02821-58873 Tel. 0800-00TRUST (=0800-0087878)
<b>Inhabitants of Spain should contact:</b>	
	<b>Spanish Office</b>
From: 9:00 – 17:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support.es@trust.com">support.es@trust.com</a> Fax +31-78-6543299 Tel. +34-902 160937
<b>Inhabitants of the Netherlands should contact:</b>	
	<b>Dutch Office</b>
From: 9:00 – 17:00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support@trust.com">support@trust.com</a> Fax 078-6543299 Tel. 0800-BELTRUST (=0800-23587878)
<b>Inhabitants of all other European countries should contact:</b>	
	<b>European Head Office</b>
From: 9.00 – 17.00	Internet <a href="http://www.trust.com">www.trust.com</a> E-mail <a href="mailto:support@trust.com">support@trust.com</a> Fax +31-78-6543299 Tel. +31-78-6549999